



Option 1



# AvatarOn

It's also a **Switch**



Option 2



# AvatarOn

It's also a **Switch**







## **Personalised for your lifestyle**


A suite of switches with customisable designs.








## Award-winning Designs: Ingenious Beauty



SS Mechanism



Conventional rocker

The ground-breaking AvatarOn series is a true marriage of aesthetics and practicality, making it a perfect choice for all home or office designs. The switches are mirror-smooth. Moreover, the revolutionary switches can be fitted with a wide variety of customisable covers, giving AvatarOn the flexibility to integrate easily into any decor styles, meeting all aesthetic needs.

Considered the perfect combination of form and function, our patented “Slim Rocker, Sure Click” SS technology not only gives AvatarOn a greater thinness overall, but also a near-zero contact jitter that reduces sparks, thus ensuring a safe and reliable use.

In 2017, AvatarOn gained international recognition for its innovative design and quality excellence and was awarded the iF Design Award – one of the world’s most authoritative and reputable industrial design awards.




# Customisable Covers for True Adaptability

AvatarOn switches are available in an array of replaceable covers for full customisation and integration into any home decor



## Modern Look

The stylish and streamlined design of AvatarOn switch covers are finished in white, soft wood, dark wood and gold hairline materials for a classic look and universal elegance.



White



Wine Gold



Dark Wood



Light Wood



Gold Hairline



## Customised Design

Stamp your style with inspiring designs. The customised pattern covers of Avaton provides you with an extra canvas to showcase your creativity in a subtle yet apparent way. Perhaps, personalised covers with photographs of loved ones and those special moments in life so they continue to touch you every day with every flick of a switch!

For more details, please contact us or visit our website: [www.schneider-electric.com.my/avaton](http://www.schneider-electric.com.my/avaton)





Designed for ease of personalization, AvatarOn switches have innovative, customizable covers that can be removed and mounted with just one hand.



A release indicator makes it easy to fit the cover into place

## Run Wild with Limitless Possibilities

As design trends are constantly evolving, home decor changes from time to time accordingly. The innovative snap-on replaceable cover design of AvatarOn gives consumers the flexibility to personalise their switches with a one-hand cover removal, as simple as changing a mobile phone case.

The unequalled design and unique glossy surface of AvatarOn faceplate serves as the perfect canvas for DIY customisation, you can now redesign your favourite covers and integrate them easily into your home decor.

# Tech-chic Design that Shines

The AvatarOn soft LED locators merges seamlessly with its sleek giant dolly, creating a stylish and streamlined design. Unobtrusive in daytime, the fluorescent LED locators glow with a soft luminescent in the dark, indicating the exact location of each switch at night. Combined with its outstanding performance, reliability, lifespan and energy saving features, the subtle glow of AvatarOn switches beautifully blends practical aesthetics with leading-edge design.



## Multifunctional Accessories for Every Day Conveniences

To meet with the demand of modern busy lifestyles, various cover designs incorporating key holders, USB charging socket with mobile phone frames are specially designed for added conveniences, efficiencies and beauty at home.

| Description   | Reference   | Unit LP [₹]   |                   |                    |                   |                             |
|---|-------------|---------------|-------------------|--------------------|-------------------|-----------------------------|
|   |             | White (WE_G8) | Wine Gold (WG_G8) | Light Wood (LW_G8) | Dark Wood (DW_G8) | Metal Gold Hairline (GH_G8) |
| <b>16A Switches</b>                                   |             |               |                   |                    |                   |                             |
| 16AX 250V 1 Gang 1 Way Switch                         | E8331L1_    | 378           | 567               | 567                | 567               | 567                         |
| 16AX 250V 1 Gang 2 Way Switch                         | E8331L2_    | 404           | 606               | 606                | 606               | 606                         |
| 16AX 250V 1 Gang 1 Way Switch with LED Indicator      | E8331L1LED_ | 567           | 850               | 850                | 850               | 850                         |
| 16AX 250V 1 Gang 2 Way Switch with LED Indicator      | E8331L2LED_ | 606           | 909               | 909                | 909               | 909                         |
| 16AX 250V 2 Gang 1 Way Switch                         | E8332L1_    | 584           | 877               | 877                | 877               | 877                         |
| 16AX 250V 2 Gang 2 Way Switch                         | E8332L2_    | 710           | 1066              | 1066               | 1066              | 1066                        |
| 16AX 250V 2 Gang 1 Way Switch with LED Indicator      | E8332L1LED_ | 877           | 1315              | 1315               | 1315              | 1315                        |
| 16AX 250V 2 Gang 2 Way Switch with LED Indicator      | E8332L2LED_ | 1066          | 1598              | 1598               | 1598              | 1598                        |
| 16AX 250V 3 gang 1 Way Switch                         | E8333L1_    | 958           | 1436              | 1436               | 1436              | 1436                        |
| 16AX 250V 3 gang 2 Way Switch                         | E8333L2_    | 1031          | 1547              | 1547               | 1547              | 1547                        |
| 16AX 250V 3 gang 1 Way Switch with LED Indicator      | E8333L1LED_ | 1436          | 2154              | 2154               | 2154              | 2154                        |
| 16AX 250V 3 gang 2 Way Switch with LED Indicator      | E8333L2LED_ | 1547          | 2320              | 2320               | 2320              | 2320                        |
| 16AX 250V 4 Gang 1 Way Switch                         | E8334L1_    | 1378          | 2067              | 2067               | 2067              | 2067                        |
| 16AX 250V 4 Gang 2 Way Switch                         | E8334L2_    | 1545          | 2377              | 2377               | 2377              | 2377                        |
| 16AX 250V 4 Gang 1 Way Switch with LED Indicator      | E8334L1LED_ | 2067          | 3101              | 3101               | 3101              | 3101                        |
| 16AX 250V 4 Gang 2 Way Switch with LED Indicator      | E8334L2LED_ | 2377          | 3566              | 3566               | 3566              | 3566                        |
| <b>16A Intermediate Switches</b>                      |             |               |                   |                    |                   |                             |
| 16AX 250V 1 Gang Intermediate Switch                  | E8331M_     | 1121          | 1682              | 1682               | 1682              | 1682                        |
| <b>10A Momentary Switches</b>                         |             |               |                   |                    |                   |                             |
| 10A 250V 1G Momentary Switch                          | E8331PRL1_  | 411           | 617               | 617                | 617               | 617                         |
| 10A 250V 2G Momentary Switch                          | E8332PRL1_  | 493           | 740               | 740                | 740               | 740                         |
| <b>Double Pole Switches</b>                           |             |               |                   |                    |                   |                             |
| 20A 250V 1 Gang Double Pole Switch with LED Indicator | E8331D20N_  | 1074          | 1611              | 1611               | 1611              | 1611                        |
| 20A 250V 2 Gang Double Pole Switch with LED Indicator | E8332D20N_  | 1289          | 1933              | 1933               | 1933              | 1933                        |
| 32A 250V 1 Gang Double Pole Switch with LED Indicator | E8331D32N_  | 1426          | 2138              | 2138               | 2138              | 2138                        |
| 45A 250V 1 Gang Double Pole Switch with LED Indicator | E8331D45N_  | 1782          | 2673              | 2673               | 2673              | 2673                        |
| <b>Bell Switch</b>                                    |             |               |                   |                    |                   |                             |
| 10A 250V Doorbell Switch                              | E8331BPL1_  | 411           | 617               | 617                | 617               | 617                         |
| <b>Sockets</b>  |             |               |                   |                    |                   |                             |
| 10A International Socket for India                    | E83426TSI_  | 1102          | 1654              | -                  | -                 | -                           |
| 10A 250V 2 Gang Universal Socket                      | E83426U2_   | 456           | 684               | 684                | 684               | 684                         |
| 10A 250V 2 Gang Universal Socket Cover                | E83426U2C_  | 137           | -                 | -                  | 205               | 205                         |
| 6/16A Switched Socket                                 | E8315_16_   | 981           | 1472              | 1472               | 1472              | 1472                        |
| 6A 2/3 Pin Switched Socket                            | E8315_6_    | 782           | 1173              | 1173               | 1173              | 1173                        |
| 6/16A Switched Socket Cover                           | E8315C_16_  | 294           | 442               | 442                | 442               | 442                         |
| 6A 2/3 Pin Switched Socket Cover                      | E8315C_6_   | 235           | 352               | 352                | 352               | 352                         |
| <b>USB Charger</b>                                    |             |               |                   |                    |                   |                             |
| 13A 250V Switched Socket with 2.1A USB Charger        | E8315USB_   | 6624          | 9936              | 9936               | 9936              | 9936                        |
| 2 Ports Max 2.1A USB Charger                          | E83311USB_  | 3897          | 5845              | -                  | -                 | -                           |
| 2 x 2.1A USB Charger                                  | E8332USB_   | 4871          | 7306              | 7306               | 7306              | 7306                        |

| Description  | Reference    | Unit LP [₹]   |                   |                    |                   |                             |
|--|--------------|---------------|-------------------|--------------------|-------------------|-----------------------------|
|  |              | White (WE_G8) | Wine Gold (WG_G8) | Light Wood (LW_G8) | Dark Wood (DW_G8) | Metal Gold Hairline (GH_G8) |
| <b>Covers</b>  |              |               |                   |                    |                   |                             |
| 1 Gang Switch Cover                                      | E8331_       | 113           | 170               | 170                | 170               | 170                         |
| 1 Gang Switch Cover with Keyholder, GH                   | E8331KH_     | 136           | 204               | 204                | 204               | 204                         |
| 2 Gang Switch Cover                                      | E8332_       | 175           | 263               | 263                | 263               | 263                         |
| 3 Gang Switch Cover                                      | E8333_       | 287           | 431               | 431                | 431               | 431                         |
| 3 Gang Switch Cover with Keyholder                       | E8333KH_     | 345           | 517               | 517                | 517               | 517                         |
| 4G Switch Cover  | E8334_       | 413           | 620               | 620                | 620               | 620                         |
| <b>Blacket/ Frame</b>                                    |              |               |                   |                    |                   |                             |
| 2 Gang Blacket   | E8331_26_    | 76            | 114               | -                  | -                 | -                           |
| 3 Gang Blacket   | E8331_36_    | 114           | 170               | -                  | -                 | -                           |
| 4 Gang Blacket   | E8331_46_    | 170           | 227               | -                  | -                 | -                           |
| <b>Blank Plates</b>                                      |              |               |                   |                    |                   |                             |
| 1 Gang Blank Plate                                       | E8330X_      | 249           | 374               | 374                | 374               | 374                         |
| 2 Gang Blank Plate                                       | E8330TX_     | 387           | 580               | 580                | 580               | 580                         |
| <b>Hotel Series</b>                                      |              |               |                   |                    |                   |                             |
| DND, PCU, PW Indicator with Bell Switch                  | E8331BPDMW_  | 3546          | 5319              | 5319               | 5319              | 5319                        |
| 250V 16A Electronic Keycard Switch                       | E8331EKT_    | 6884          | 10327             | 10327              | 10327             | 10327                       |
| Panic Button with Key Reset                              | E8331KPB_    | 944           | 1417              | 1417               | 1417              | 1417                        |
| 10A 2 Gang Mechanical Curtain Switch                     | E8332C_      | 735           | 1103              | 1103               | 1103              | 1103                        |
| 16AX 3 Gang Switch with PCU, DND, PW Sym                 | E8333DMWS_   | 3439          | 5159              | 5159               | 5159              | 5159                        |
| Night Foot Lamp with LED Illumination                    | E8390FLW_    | 1300          | 1950              | 1950               | 1950              | 1950                        |
| 115/240V 20VA Universal Version Shaver                   | E83T727V_    | 3891          | 5836              | 5836               | 5836              | 5836                        |
| <b>Telecom, Network, Connectivity &amp; Media Series</b> |              |               |                   |                    |                   |                             |
| 13A 250V 1 Gang Fused Con Unit                           | E8330FSG_    | 626           | 939               | 939                | 939               | -                           |
| 13A 250V 1 Gang Fused Con Unit with Neon                 | E8330FSGN_   | 845           | 1267              | 1267               | 1267              | -                           |
| 13A 250V 1 Gang Fused Con with DP Switch and Neon        | E8331DFSGN_  | 2112          | 3168              | 3168               | 3168              | -                           |
| RCA/S-Video Socket                                       | E8331RCA_S_  | 1500          | 2250              | -                  | -                 | -                           |
| 1 Gang S Keystone Wallplate (w/o Mod)                    | E8331RJS_    | 400           | 600               | -                  | -                 | -                           |
| 1 Gang Telephone Socket, Shuttered Wallplate             | E8331RJS4_   | 601           | 902               | 902                | 902               | 902                         |
| 1 Gang RJ45 Data Cat5E, Shuttered                        | E8331RJS5_   | 939           | 1408              | 1408               | 1408              | 1408                        |
| 1 Gang RJ45 Data Cat6, Shuttered                         | E8331RJS6_   | 1121          | 1682              | -                  | -                 | -                           |
| Speaker Connection, One Pair                             | E8331SC_     | 1300          | 1950              | -                  | -                 | -                           |
| 25A 250V 1 Gang Conn Unit                                | E8331TB_     | 939           | 1408              | 1408               | 1408              | 1408                        |
| 1 Gang TV Socket, 75Ω, Through-Connect                   | E8331TV_     | 473           | 709               | 709                | 709               | 709                         |
| 1 Gang TV Socket, Slave 5-1000                           | E8331TVSF_   | 472           | 710               | -                  | -                 | -                           |
| Volume control, 5W, 80hm                                 | E8331VC_     | 1700          | 2550              | -                  | -                 | -                           |
| VGA + mini Audio   | E8332HD15PH_ | 1500          | 2250              | -                  | -                 | -                           |
| 2 Gang HDMI+HDMI , Keystone on Wallplate                 | E8332HDHD_   | 2137          | 3205              | -                  | -                 | -                           |
| HDMI + RJ45 Data Cat5E, Shuttered                        | E8332HDRJS5_ | 2371          | 3556              | -                  | -                 | -                           |
| HDMI + USB Soc   | E8332HDUSB_  | 3897          | 5845              | -                  | -                 | -                           |
| 2 Gang S Keystone Wallplate (w/o Mod)                    | E8332RJS_    | 750           | 1125              | -                  | -                 | -                           |
| 2G Tel Socket, Shuttered Wallplate,                      | E8332RJS4_   | 1408          | 2112              | -                  | -                 | -                           |
| 2 Gang RJ45 Data Cat5E, Shuttered                        | E8332RJS5_   | 1639          | 2459              | 2459               | 2459              | 2459                        |
| 2 Gang RJ45 Data Cat6, Shuttered                         | E8332RJS6_   | 2103          | 3154              | -                  | -                 | -                           |
| Speaker Connection, Two Pair                             | E8332SC_     | 2000          | 3000              | -                  | -                 | -                           |
| 1 Gang Tel + RJ45 Data Cat5E, Shuttered                  | E8332TDRJS5_ | 1408          | 2112              | 2112               | 2112              | 2112                        |
| 2 Gang TV Master/FM Socket                               | E8332TVFMM_  | 1900          | 2850              | 2620               | -                 | -                           |
| 1 Gang TV+ RJ45 Data Cat5E, Shuttered                    | E8332TVRJS5_ | 1746          | 2620              | -                  | 2620              | 2620                        |
| 1 Gang TV+ RJ45 Data Cat6, Shuttered                     | E8332TVRJS6_ | 1746          | 2620              | -                  | 2620              | 2620                        |

Life Is n

**Schneider**  
 Electric

Schneider Electric India Pvt. Ltd.  
Corporate Office  
9th Floor, DLF Building No.10,  
Tower C, DLF Cyber City, Phase II,  
Gurgaon - 122002, Haryana.  
Tel: 0124 3940400, Fax: 0124 4222036  
[www.schneider-electric.co.in](http://www.schneider-electric.co.in)

**Customer Care Centre**  
Toll-free numbers: 1800 103 0011, 1800 425 4272  
General number: 0124 4222040  
Email: [in.campaign@schneider-electric.com](mailto:in.campaign@schneider-electric.com)