

Current & Voltage Transformer Basics



Ken Sonnenberg
GE Multilin / Instrument Transformers, Inc.

Agenda

Current Transformers

- Transformer Ratio
- Polarity
- IEEE Metering Accuracy
- IEEE Relaying Accuracy
- Accuracy Influencing factors
- Burden Calculation
- Rating Factor

Voltage Transformers

- IEEE Accuracy Classes
- Installation Guidelines

Required Information for Specifying CTs & VTs

“Take Home Rules” for CTs & VTs

Transformer ratio (TR)

$$\text{Transformer Ratio} = \frac{\text{Primary Current}}{\text{Secondary Current}}$$


Primary Current
(100 amps)



Secondary
Current
(5 amps)

$$\frac{100}{5} = 100:5 \text{ or } 20:1$$

Polarity




Remember:

Primary current into “polarity” =

Secondary current out of “polarity”

Polarity



Remember:

Primary current into “non-polarity” =

Secondary current out of “non-polarity”₈

CT Metering Accuracy

**Actual secondary
current**



**Rated
secondary
current**

Difference in % is known as
the “**Accuracy**”
of the CT

IEEE CT Metering Accuracy

Accuracy Class (*)

Application

0.15	High Accuracy Metering
0.15S	“Special” High Accuracy Metering
0.3	Revenue Metering
0.6	Indicating Instruments
1.2	Indicating Instruments

* All accuracy classes defined by IEEE C57.13 or C57.13.6

* Accuracy classes include both ratio & phase angle error

IEEE CT Metering Accuracy

Burden

Load connected to CT secondary

Includes devices & connecting leads

Expressed in ohms

Standard values = B0.1, B0.2, B0.5, B0.9, B1.8

E0.04, E0.2

All burdens defined by IEEE C57.13 or C57.13.6 for 60 Hz only

IEEE CT Metering Accuracy

Standard IEEE CT Burdens (5 Amp)
(Per IEEE Std. C57.13-1993 &
C57.13.6)

Application	Burden Designation	Impedance (Ohms)	VA @ 5 amps	Power Factor
Metering	B0.1	0.1	2.5	0.9
	B0.2	0.2	5	0.9
	B0.5	0.5	12.5	0.9
	B0.9	0.9	22.5	0.9
	B1.8	1.8	45	0.9
	E0.2	0.2	5	1.0
	E0.04	0.04	1	1.0

IEEE CT Metering Accuracy

“Accuracy” expressed as:

		<u>Typical Examples</u>
Accuracy Class	+ Burden (Ohms) =	
(0.3, 0.6, 1.2) (*)	(B0.1, B0.2, B0.5, B0.9, B1.8)	0.3B0.2 0.6B0.9 1.2B1.8
(0.15*, 0.15S^)	E0.2, E0.04)	0.15E0.2


* Accuracy class is stated at 100% rated current

* At 10% rated current, twice the error is allowed (5% for 0.15 class)


^ Accuracy class is stated at 100% to 5% rated current

IEEE CT Metering Accuracy


IEEE C57.13 Accuracy
0.3 @ BX.X; RF 4.0




IEEE CT Metering Accuracy




IEEE CT Metering Accuracy



IEEE CT Metering Accuracy



IEEE CT Metering Accuracy



IEEE CT Relay Accuracy

Standard Relay Accuracy Classes

C or T100

C or T200

C or T400

C or T800

What do these mean?

IEEE CT Relay Accuracy

Relay class (C or T___) designates minimum secondary terminal volts...

At 20 times rated current

Without exceeding 10% ratio error


Into a maximum specified burden

*Now that everyone is totally confused
let's look at some simple examples*

...

IEEE CT Relay Accuracy

C or T100 example




Terminal Volts = (20 times rated) (Total external burden)

$$100 \text{ Volts} = (100 \text{ amps}) (1.0 \text{ Q})$$

IEEE CT Relay Accuracy

C or T200 example




$$\text{Terminal volts} = (20 \text{ times rated}) (\text{Total external burden})$$
$$200 \text{ Volts} = (100 \text{ amps}) (2.0 \text{ } \Omega)$$

IEEE CT Relay Accuracy

Standard IEEE CT Burdens (5 Amp)
(Per IEEE Std. C57.13-1993)

Application	Burden Designation	Impedance (Ohms)	VA @ 5 amps	Power Factor
Relaying	B1	1	25	0.5
	B2	2	50	0.5
	B4	4	100	0.5
	B8	8	200	0.5

IEEE CT Relay Accuracy



Factors Influencing CT Accuracy

Frequency

“Low frequency” and “High accuracy” are not friends!!

Current Ratio


“Low ratio” and “high accuracy” are not friends!!

Burden

“High burden” and “High Accuracy” are not friends!!

CT Burden Calculation

How do we calculate this?



CT Burden Calculation

$$Z_T = R_{CT} + R_L + Z_B$$

Z_T = Total burden in ohms (vector summation of resistance and inductance components)

R_{CT} = CT secondary resistance in ohms @75 deg C (DCR)

R_L = Resistance of leads in ohms (Total loop distance)

Z_B = Device impedance in ohms

Assumption: 3 phase CTs are “Y” connected

CT Rating Factor (RF) -- IEEE

Rated current \times (RF) =

Maximum continuous current carrying
capability:


Without exceeding temperature limits

Without loss of published accuracy class

Typical rating factors -- 1.0, 1.33, 1.5, 2.0, 3.0, 4.0

CT Rating Factor (RF) -- IEEE

IEEE C57.13 Accuracy
0.3% @ BX.X RF 4.0



IEEE VT Accuracy Class

Metering Accuracy Classes (% error)

0.3

Defined by IEEE C57.13

0.6

Applicable from 90% to 110%
rated voltage

1.2

0.15

— Defined by IEEE C57.13.6

IEEE VT Accuracy Class

Metering Accuracy
Class Burdens

	VA	PF
W	12.5	0.10
X	25	0.70
M	35	0.20
Y	75	0.85
Z	200	0.85
ZZ	400	0.85

These standard burden designations have no significance at frequencies other than 60 Hz.

IEEE VT Accuracy Class

Expressed as:

Accuracy Class + Burden Code

0.3 W,X,Y

0.6 Z

1.2 ZZ

These standard designations have no significance
at frequencies other than 60 Hz.

VT Installation Guidelines

Caution:

Rated voltage: Do not operate above 110%

Line to ground rated:

Do not connect line to line

Do not use on ungrounded systems
w/o consulting factory

Rated Frequency: Do not operate below rated
frequency w/o consulting
factory

Required Information for Specifying CTs

Current Transformer RFQ Specification Sheet

Environment: Indoor Outdoor

Insulation Level Required: MV

System Voltage (kV) Power Frequency (kV) BL (kV) IEEE IEC

CT application: Metering Protection

Max. Outside dimensions: _____ Max. Depth: _____

Transformer window size (if applicable): inches mm

Round: Rectangular: Primary Bar: Yes	Diameter: Height x No.	Width:
--	------------------------------	--------

Current ratio: : 5 : 1 : other

Indicating only application: % of _____ VA (for metering and protection selection)

Metering class:

IEEE -	<input type="checkbox"/> 0.3	<input type="checkbox"/> 0.6	<input type="checkbox"/> 1.2	<input type="checkbox"/> 2.4	<input type="checkbox"/> other
IEC -	<input type="checkbox"/> 0.2	<input type="checkbox"/> 0.5	<input type="checkbox"/> 1.0	<input type="checkbox"/> other	

Metering burden:

IEEE -	00.1	00.2	00.5	00.9	01.0	other
IEC -	0.066	0.033	0.016	0.009	0.004	other

Protection Class: C for IEEE VA, P for IEC

Operating Frequency: 50 Hz 60 Hz

Rating Factor: 1.0 1.33 1.5 2.0 other

Secondary Connections: terminals 24" leads Other (Specify below)

Outer Insulation: Standard Cotton Tape and Varnish Polyester Tape

Insulation Class: 105 °C (standard) Other

Other Special Requirements (dimensional constraints, mounting requirements, other performance requirements, etc):

Required Information for Specifying VTs

Voltage Transformer (VT) RFQ Specification

Environment: Indoor Outdoor

System Voltage (KV)	Power Frequency (KV)	RM (KV)	Standard (check one)
0.6	4	38	IEEE <input type="checkbox"/>
0.72	3	—	IEC <input type="checkbox"/>
3.0	10	40	IEC <input type="checkbox"/>
4.8	16	60	IEEE <input type="checkbox"/>
7.2	20	60	IEC <input type="checkbox"/>
8.7	36	75	IEEE <input type="checkbox"/>
12	38	78	IEC <input type="checkbox"/>
15	34	110	IEEE <input type="checkbox"/>
24	50	125	IEC <input type="checkbox"/>
25	60	125	IEEE <input type="checkbox"/>
34.5	70	150	IEEE <input type="checkbox"/>
34.5	70	200	IEEE <input type="checkbox"/>

Frequency: 50 HZ 60 HZ

Accuracy: IEEE: W X H Y Z ZZ
Enter 0.5, 0.6, 1.2 or leave blank.

IEC: 10VA 25VA 50VA 100VA 200VA
500VA other
Enter 0.2, 0.5, 1.0 or leave blank.

Thermal Rating: VA optional

Primary Voltage: 1 bushing V_{pc} - phase to neutral
2 bushing V_{pc} - phase to phase

Secondary Voltage: 120V 115V 110V 100V
 $120/\sqrt{3}$ $115/\sqrt{3}$ $110/\sqrt{3}$ $100/\sqrt{3}$
 other

Rated Voltage Factor (1 bushing only): 1.0 for 30s 1.9 for 8 hours
 other

Fuses:	Primary	Secondary	None	Voltage
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	600 - 720 V
<input type="checkbox"/>	N/A	<input type="checkbox"/>	<input type="checkbox"/>	2.5 KV - 15 kV

Note: Integral fusing not available above 15 kV

Take Home Rule # 1

Never open circuit a current transformer secondary while the primary is energized

CTs are intended to be proportional current devices. Very high voltages can result from open circuiting the secondary circuit of an energized CT. Even very small primary currents can cause damage... Consult the factory if you have questions.

Take Home Rule # 2

Never short circuit the secondary of an energized VT

VTs are intended to be used as proportional voltage devices. Damaging current will result from short circuiting the secondary circuit of an energized VT.

Take Home Rule # 3

Metering applications
do not require a “C” class CT

“C” class ratings are specified for protection purposes only. With some exceptions metering class CTs are typically smaller and less expensive.

Take Home Rule # 4

CT secondary leads must be added to the CT burden

Electronic relays usually represent very little burden to the CT secondary circuit. In many cases the major burden is caused by the CT secondary leads.

Take Home Rule # 5

Never use a 60 Hz rated VT
on a 50 Hz System

60 Hz VTs may saturate at lower frequencies and exceed temperature limitations. VT failure is likely...severe equipment damage is possible.

Take Home Rule # 6

Exercise caution when connecting grounded VTs to ungrounded systems

Line to ground voltage on any VT may exceed the primary voltage rating during a fault condition...
VT must be designed for application.

QUESTIONS?





Backup Data

CT Burden Calculation

1. For single phase or zero sequence applications:

$$\text{Total burden: } Z_t = R_{ct} + 2 \cdot R_I + Z_b$$

2. For three phase connections:

The burden on individual CTs varies with the type of connection, fault and applications:

Connection method and CT location	Type of Fault/Application	
	3 Phase, Ph. to Ph. or Metering	Phase to ground
Y (connected at CT)	$Z_t = R_{ct} + R_I + Z_b$	$Z_t = R_{ct} + 2 \cdot R_I + Z_b$
Y (connected at relay or meter)	$Z_t = R_{ct} + 2 \cdot R_I + Z_b$	$Z_t = R_{ct} + 2 \cdot R_I + Z_b$
Delta (connected at relay or meter)	$Z_t = R_{ct} + 2 \cdot R_I + 3 \cdot Z_b$	$Z_t = R_{ct} + 2 \cdot R_I + 2 \cdot Z_b$
Delta (connected at CT)	$Z_t = R_{ct} + 3 \cdot R_I + 3 \cdot Z_b$	$Z_t = R_{ct} + 2 \cdot R_I + 2 \cdot Z_b$

Z_t : Total burden seen by the CT in Ω used for calculating required CT excitation voltage (E_s).

$Z_{te} = Z_t - R_{ct}$: Total CT external burden in Ω used for calculating required CT relay class.

R_{ct} : CT's secondary winding resistance in Ω . Also include any relay impedance that is inside the delta connection.

R_I : One way leads burden in Ω .

Z_b : Relay impedance in Ω .

So, optimum CT performance (lowest burden) will therefore be obtained if Y connected CTs are interconnected at the CT location and delta connected CTs are interconnected at the relay location.

CT Burden Calculation -- Auxiliary CT (ACT)

- 1 Calculate ACT primary impedance (Z_{pri}) converted from ACT secondary burden (Z_{sec})

$$(I_{pri})^2 \cdot Z_{pri} = (I_{sec})^2 \cdot Z_{sec}$$

$$Z_{pri} = (I_{sec}/I_{pri})^2 \cdot Z_{sec}$$

$$I_{sec} = \text{ACT secondary current (A)}$$

$$I_{pri} = \text{ACT primary current (A)}$$

- 2 Calculate total burden (Z_{tmct}) on main CT

$$Z_{tmct} = Z_{bm} + Z_{pri} + Z_{act}$$


$$Z_{tmct} = Z_{bm} + [(I_{sec}/I_{pri})^2 \cdot Z_{sec}] + Z_{act}$$

$$Z_{bm} = \text{Burden on the main CT (including leads) w/o ACT } (\Omega)$$


$$Z_{sec} = \text{Burden on the ACT, including leads burden } (\Omega)$$

$$Z_{act} = \text{Burden of the ACT itself } (\Omega)$$

Comparison of Different VT Connections for GF Detection & Ferroresonance Damping



Y-Y with damping resistor connected between the VT primary neutral and the ground or connected parallel with the VT secondary windings



Y-Broken Delta Δ with damping resistor and 59G relay connected across the VT secondary broken corner delta

❑ Resistor connected in primary

It has to use high voltage resistor that involves high cost and more space.

❑ Use 3 resistors connected in Y connected secondary

3 resistors are needed and power loss occurs at system normal condition

➤ Y-Broken Corner Delta is a preferred method

IEC CT Metering Accuracy Class

(Per IEC 60044-1)

Class	± Percentage current (ratio) error at percentage current shown below				± Phase displacement at percentage of rated current shown below							
					Minutes				Centiradians			
	5	10	100	120	5	20	100	120	5	20	100	120
0.1	0.4	0.2	0.1	0.1	15	8	5	5	0.45	0.24	0.15	0.15
0.2	0.75	0.35	0.2	0.2	30	15	10	10	0.90	0.45	0.30	0.30
0.5	1.5	0.75	0.5	0.5	90	45	30	30	2.70	1.35	0.90	0.90
1.0	3.0	1.5	1.0	1.0	180	90	60	60	5.40	2.70	1.80	1.80

Class	± Percentage current (ratio) error at percentage current shown below	
	50 % Current Rating	120% Current Rating
3.0	3	3
5.0	5	5

- Conditions:
1. PF = 0.8 lagging
 2. Burden = 25%-100% of rated burden for Classes 0.1-1.0
 3. Burden = 50%-100% of rated burden for Classes 3.0-5.0

IEC CT Metering Accuracy Class

(Per IEC 60044-1)

Standard IEC
Metering /Relaying Burdens (VA)
50 / 60 Hz

2.5

5

10

15

30

40

IEC CT Metering Accuracy Class

(Per IEC 60044-1)

“Accuracy” expressed as:

Burden (VA) Accuracy Class

Typical Examples:


2.5 VA class 0.2

10 VA class 1.0

15 VA class 0.5

IEC CT Relay Accuracy

(Per IEC 60044-1)



Extended Current Rating IEC 60044-1

Similar to IEEE CT Rating Factor (RF)

Expressed as a percentage of the rated primary current

Standard values are 120%, 150% & 200%

For example: IEC extended current rating = 200%

Is very similar to

IEEE CT rating factor (RF) = 2

Instrument Security Factor (FS)

(Per IEC 60044-1)

Defines the minimum excitation current (I_{exc}) of the CT (horizontal axis of excitation curve) at the secondary limiting e.m.f. (vertical axis of excitation curve):

$$\underline{I_{exc}} \geq FS \bullet I_{sn} \bullet 10\%$$

I_{sn} = Rated secondary current

$$\underline{\text{Secondary limiting e.m.f.}} = FS \bullet I_{sn} \bullet (\text{Rated Burden} + R_{ct})$$

R_{ct} = Internal resistance of the CT @ 75 deg C usually expressed in ohms

“Rated Burden” usually expressed in VA. Convert to ohms by dividing VA by $(I_{sn})^2$

Let's look at a typical example

Instrument Security Factor (FS)

(Per IEC 60044-1)

Typical example: 10VA class 0.5 FS 5

$$I_{exc} \geq FS \cdot I_{sn} \cdot 10\%$$

$$I_{exc} \geq 5 \cdot 5 \cdot 10\% \geq 2.5 \text{ amps}$$

Secondary limiting e.m.f. = $FS \cdot I_{sn} \cdot (\text{Rated Burden} + R_{ct})$

Reference excitation curve to verify $I_{exc} \geq 2.5$ amps at the calculated secondary limiting e.m.f.

Note: High accuracy class and low FS requirements may not be possible

IEC VT Accuracy Class

Per IEC 60044-2

Metering VTs

Metering Accuracy Class	± Percentage voltage (ratio) error	± Phase displacement	
		Minutes	Centiradians
0.1	0.1	5	0.15
0.2	0.2	10	0.30
0.5	0.5	20	0.60
1.0	1.0	40	1.20
3.0	3.0	Not specified	Not specified

Conditions:

PF = 0.8 lagging

Voltage range = 80% -120% of rated voltage

Burden range = 25% - 100% of rated burden.

IEC VT Accuracy Class

Per IEC 60044-2

Relaying VTs

Relaying Accuracy Class	\pm Percentage voltage (ratio) error	\pm Phase displacement	
		Minutes	Centiradians
3P	3.0	120	3.5
6P	6.0	240	7.0

Conditions:

PF = 0.8 lagging

Voltage range = 5% rated voltage to RVF*rated voltage

Burden range= 25% - 100% rated burden

IEEE/ANSI does not have VT relaying classes. It uses metering classes for relay applications

IEC VT Accuracy Burdens

Per IEC 60044-2

Standard Burdens (VA)		Preferred Burdens (VA)	
10	100	10	
15	150	25	
25	200	50	
30	300	100	
50	400	200	
75	500	500	

IEC VT Accuracy Class

Per IEC 60044-2

Expressed as:

Frequency + Burden + Accuracy Class

50 Hz, 25 VA, class 0.5

50 Hz, 30 VA, class 3P

The accuracy designation may also include the RVF (Rated Voltage Factor) specifying the maximum allowable operating voltage level

IEC VT Rated Voltage Factor (RVF)

Per IEC 60044-2

Multiplying factor applied to primary voltage rating

Specifies maximum voltage and associated time period

Must be specified for line to ground applications involving non effectively grounded systems and line to ground rated primary voltages

IEC VT Rated Voltage Factor (RVF)

Per IEC 60044-2

RVF	Rated Time	Method of connecting the primary winding and system grounding conditions
1.2	Continuous	Between phases in any network Between transformers star-point and ground in any network
1.2	Continuous	Between phase and ground in an effectively grounded neutral system
1.5	30 seconds	
1.2	Continuous	Between phase and ground in a non-effectively grounded neutral system with automatic ground-fault tripping
1.9	30 seconds	
1.2	Continuous	Between phase and ground in an isolated system without automatic ground-fault tripping or in a resonant grounded system without automatic ground-fault tripping
1.9	8 hours	
Notes: Reduced rated times are permissible by agreement between manufacturer and user.		
All standard designs meet 1.2 continuous.		

VT Thermal Ratings

Typical ratings @ 30 deg C ambient

Low voltage

150 VA

300 VA

750 VA

Med Voltage

600 VA

750 VA

1500 VA

Note these values are typically much higher than the rated accuracy burdens

IEC products not required to refer to thermal ratings

Current Transformer (CT) RFQ Specification

Environment: ___Indoor ___Outdoor

System Voltage (kV)	Power Frequency (kV)	BIL (kV)	Standard (Check one)
0.6	4	10	IEEE ___
0.72	3		IEC ___
3.6	10	40	IEC ___
5.0	19	60	IEEE ___
7.2	20	60	IEC ___
8.7	26	75	IEEE ___
12	28	75	IEC ___
15	34	110	IEEE ___
24	50	125	IEC ___
25	40	125	IEEE ___
34.5	70	150	IEEE ___
34.5	70	200	IEEE ___

CT Application: ___Metering ___Protection

Dimensions: ___ Inches ___ mm

Max. Outside: L _____ x W _____ x D _____

CT Window: Round: _____ Diameter; Rectangular: L _____ x W _____ ; Primary Bar: _____

Current Ratio: _____ : 5 _____ : 1

Continued next slide

Current Transformer (CT) RFQ Specification (Continued)

Accuracy:

Indication Only: _____ %, _____ VA (Skip metering & protection selections)

Metering Class:

IEEE: _____ 0.3 _____ 0.6 _____ 1.2 _____ 2.4 _____ Other

IEC: _____ 0.2 _____ 0.5 _____ 1.0 _____ Other

Metering Burden:

IEEE (Ohms): _____ B0.1 _____ B0.2 _____ B0.5 _____ B0.9 _____ B1.8 _____ Other

IEC (VA): _____ 2.5 _____ 5.0 _____ 10 _____ 15 _____ 30 _____ Other

Protection Class: C _____ (IEEE) _____ VA, _____ P _____ (IEC)

Operating Frequency: _____ 60HZ _____ 50HZ

Rating Factor: _____ 1.0 _____ 1.33 _____ 1.5 _____ 2.0 _____ Other

Secondary Connections: _____ Terminals _____ 24 inch leads

Outer Insulation: _____ Standard _____ Cotton tape & varnish _____ Polyester tape

Insulation Class: _____ 105 °C (Standard) _____ Other

Other Special Requirements (dimensional constraints, mounting requirements, ...etc):

Voltage Transformer (VT) RFQ Specification

Environment: Indoor Outdoor

System Voltage (kV)	Power Frequency (kV)	BIL (kV)	Standard (Check one)
0.6	4	10	IEEE <input type="checkbox"/>
0.72	3		IEC <input type="checkbox"/>
3.6	10	40	IEC <input type="checkbox"/>
5.0	19	60	IEEE <input type="checkbox"/>
7.2	20	60	IEC <input type="checkbox"/>
8.7	26	75	IEEE <input type="checkbox"/>
12	28	75	IEC <input type="checkbox"/>
15	34	110	IEEE <input type="checkbox"/>
24	50	125	IEC <input type="checkbox"/>
25	40	125	IEEE <input type="checkbox"/>
34.5	70	150	IEEE <input type="checkbox"/>
34.5	70	200	IEEE <input type="checkbox"/>

Operating Frequency: 60HZ 50HZ

Accuracy:

IEEE: W X M Y Z ZZ Other
 (Enter 0.3, 0.6, 1.2, or leave blank)

IEC: 10VA 25VA 50VA 100VA 200VA 500VA Other
 (Enter 0.2, 0.5, 1.0, or leave blank)

Continued next slide

Voltage Transformer (VT) RFQ Specification (Continued)

Thermal Rating: _____VA (Optional)

Primary Voltage: ___1 bushing _____V_{AC} - Phase to neutral

___2 bushing _____V_{AC} - Phase to phase

Secondary Voltage: _____120V _____115V _____110V _____100V

___120/√3 _____115/√3 _____110/√3 _____100/√3

___Other _____

Rated Voltage Factor (RVF) (1 bushing only): ___1.9 for 30s ___1.9 for 8 hours ___Other _____

Fuses:

___Primary ___Secondary ___None (600 – 720 V)

___Primary ___Live parts only ___Switchgear Style ___Unfused (2.5kV – 15kV)

Note integral fusing not available above 15kV

Ferroresonance

Possible with Y connected grounded VTs on ungrounded power systems

A VT is an inductive component

Capacitance to ground exists in the system

When they match ferroresonance may occur

May cause higher VT voltages & saturation

Possible results -- High VT currents

Overheating

VT failure

Ferroresonance

Recommended reading:


“Ferroresonance of Grounded Potential Transformers on Ungrounded Power Systems”

AIEE Power Apparatus & Systems,

Aug 1959, pg 607-618, by Karlicek and Taylor

Ferroresonance Damping


Preferred method



Ferroresonance Damping

Preferred method

Y-Y/Broken Corner Δ Connection



Double secondary VT

(1) Relaying / Metering

(1) Ground fault detection
and ferroresonance damping

Ferroresonance Damping




ACCURACY CLASS:
 0.2 B00F0 1.00% at 100% rated voltage with 100A loaded ANSI burden
 0.2 B00F0 1.00% at 100% rated voltage with 60 VA loaded ANSI burden

FREQUENCY:
 60 Hz

PRIMARY SYSTEM VOLTAGE:
 110V, 120V

THEMEAL RATING:
 2000 VA at 100°C amb
 3000 VA at 115°C amb
 Approximate weight 60 lbs. unloaded



TYPE 1-110-0-0-0				CAGGLED NUMBER			
GROUP	PRIMARY VOLTAGE	APPRO	SECONDARY VOLTAGE	UNIPOLAR	POLAR	RESISTANCE ONLY	INTERMEDIATE TYP
1	110V	100V	1.00%	PTGS-1-110-0-0-0	PTGS-1-110-0-0-0	PTGS-1-110-0-0-0	PTGS-1-110-0-0-0
2	110V	100V	1.00%	PTGS-1-110-0-0-0	PTGS-1-110-0-0-0	PTGS-1-110-0-0-0	PTGS-1-110-0-0-0
3	110V	100V	1.00%	PTGS-1-110-0-0-0	PTGS-1-110-0-0-0	PTGS-1-110-0-0-0	PTGS-1-110-0-0-0
4	110V	100V	1.00%	PTGS-1-110-0-0-0	PTGS-1-110-0-0-0	PTGS-1-110-0-0-0	PTGS-1-110-0-0-0
5	110V	100V	1.00%	PTGS-1-110-0-0-0	PTGS-1-110-0-0-0	PTGS-1-110-0-0-0	PTGS-1-110-0-0-0

TYPE 2-110-0-0-0				CAGGLED NUMBER			
GROUP	PRIMARY VOLTAGE	APPRO	SECONDARY VOLTAGE	UNIPOLAR	POLAR	RESISTANCE ONLY	INTERMEDIATE TYP
6	110V	100V	1.00%	PTGS-2-110-0-0-0	PTGS-2-110-0-0-0	PTGS-2-110-0-0-0	PTGS-2-110-0-0-0
7	110V	100V	1.00%	PTGS-2-110-0-0-0	PTGS-2-110-0-0-0	PTGS-2-110-0-0-0	PTGS-2-110-0-0-0
8	110V	100V	1.00%	PTGS-2-110-0-0-0	PTGS-2-110-0-0-0	PTGS-2-110-0-0-0	PTGS-2-110-0-0-0
9	110V	100V	1.00%	PTGS-2-110-0-0-0	PTGS-2-110-0-0-0	PTGS-2-110-0-0-0	PTGS-2-110-0-0-0
10	110V	100V	1.00%	PTGS-2-110-0-0-0	PTGS-2-110-0-0-0	PTGS-2-110-0-0-0	PTGS-2-110-0-0-0

RY	R _{FR} (c)
	65
	65
	65
	65
	65
	65

Ferroresonance damping resistor R_{FR} value

Based on 2 variables:

Air core inductance of primary winding (L_a)

VT ratio (N)


$$R_{FR} = 100 L_a / N^2$$

Power rating (watts) of the resistor is a system related problem. Jim Bowen's paper suggests 50% of VA rating of a single VT.


IEEE VT Groups

VT Group	No. of Bushing	Connection Method	Neutral Grounding	Notes
1	2	open Δ Y-Y possible	Any	Withstand 25% over rated voltage on an emergency basis
2	2	open Δ Y-Y possible	Any	Withstand 10% over rated voltage continuously. Primary rated for line to line voltage.
3	1	Y-Y-Y	Any	Outdoor, two secondary windings. Withstand 10% over rated voltage continuously.
4A	1	Y-Y	Effectively	Withstand 10% over rated voltage continuously & 25% on an emergency basis. For operation at 100% rated voltage.
4B	1	Y-Y Y-Broken Corner Δ	Non-effectively	Withstand 10% overvoltage continuously. For operation at 58% rated voltage.
5	1	Y-Y	Effectively	Outdoor. Withstand 40% over rated voltage for 1 minute and 10% over rated voltage continuously

VT Typical Connections



Open Delta Connection
(2) Double Bushing VTs



Y – Y Connection
(3) Single Bushing VTs

Short-Time Thermal Current Rating

One (1) – second thermal rating

Expressed as value of RMS primary current

Main influencing factor:

CT primary & secondary wire size

Can be converted to thermal rating for any time period (t) up to five (5) seconds:

$$I_{1\text{-sec}} = I \sqrt{t}$$

Tips for Avoiding CT Saturation

Use higher ratio CTs

Use separate set of high ratio CTs for high fault current tripping

Reduce secondary burden

- Select low burden relays & meters

- Distribute single phase burdens among phases

- Increase size of secondary leads

- Reduce length of secondary leads

Use “step down” auxiliary CTs